

Simple Spa Start-up

Here is the easiest FROG start-up list ever with helpful videos and infographics.

1. Drain, clean and refill your hot tub with fresh water.
2. Balance your water using our helpful [balancing infographic](#).
3. Pour one [FROG Jump Start](#) shock packet into the hot tub.
4. Replace your FROG Serene Mineral Cartridge – set it to #6 and snap into the green holder.
5. Set your FROG Serene Bromine Cartridge per the chart and snap into the holder.

System Setting Chart	
200 Gallons	0
250 Gallons	1
300 Gallons	1
350 Gallons	2
400 Gallons	3
450 Gallons	4
500 Gallons	5
550 Gallons	5
600 Gallons	6

6. Use [FROG Test Strips](#) to maintain water balance and to ensure your bromine level is always 1.0 to 2.0 ppm.

Need help? Please call our Customer Service Department at 800-222-0169 Mon-Fri 8-5 Central.